

Rainwater Diverter

www.water-tanks.net

1

Cut a 26mm circular hole 100mm from the top



2

Taking a level line from the bottom of the hole, mark the rainwater pipe to be cut. From this line mark a second line 30mm above it.



3

Cut the Rainwater Pipe on both marks and fit the Rain Diverter making sure the directional arrow points down. (Pipe clips may be needed for support)



4

Fit tank connector to water butt, making sure rubber washers are on both the inside and outside. Extend flexible hose to connect Rain Diverter to water butt, trim to size if less than 500mm from downpipe

